AZ Controller

Preset for X-Touch One (custom CUBASE layout)

X-Touch One key name	Function	SHIFT-function (hold Scrub to SHIFT)
CHANNEL		
Beats / Time	Toggle time display (MBT / SMPTE)	Show/Hide Dock
Master Level	Master select	-
Ch. Select	Channel select	-
Ch. Mute	Channel Mute	Unmute All Tracks/Busses
Ch. Solo	Channel Solo	Unsolo All Tracks/Busses
Ch. Rec	Channel Arm / Disarm	Disarm All Tracks
FUNCTION section		
F1	Insert Audio Track	Insert Midi Track
F2	Insert From Template (Can use Arrows and Shift-Zoom (enter) to select)	Insert Track Folder
F3	Toggle Tracks/Busses (Monitored on device)	Insert Stereo Bus
F4	Toggle Input Echo (Monitored)	Select All / Export
Automation Read	Automation Read (Monitored)	Toggle all read Automation
Automation Write	Automation Arm / Disarm (Monitored)	Disarm all Write automation
TRANSPORT		
Undo	Undo	Undo History
Redo	Redo	Split Clips at Now
Cycle	Toggle Loop	Set Loop points to selection
Punch In	Toogle Rewind to Now-marker on Stop	Set Punch points to selection
Previous Marker	Previous Marker	Show Console
Set Marker	Insert new marker	Select all between previous marker and next (for cycle / punchin)
Next Marker	Next Marker	Show PRV
<<	Rewind	Go to start (RTZ)
>>	Fast Forward	Go to end
Stop	Stop	Reset MIDI & Audio
Play	Pay	Run/Stop Audio Engine
Record	Record	Save
OTHER CONTROLS		
Fader	Volume	-
Fader1 (touch)	Channel select	-
Pan < - >	Pan	-
Push	Centre Pan	-
Fader Bank <	Previous Fader Bank	Go to First group of 8
Fader Bank >	Next Fader Bank	Go to Last Group of 8
Channel <	Previous Channel	-
Channel >	Next Channel	-
Left	Left / Horizontal Zoom	Shift-Tab
Right	Right / Horizontal Zoom	Tab
Up	Up / Vertical Zoom	-
Down	Down / Vertical Zoom	-
Zoom	Toggle Zoom Fits all tracks to screen on exit	Enter
Jog wheel	Scroll Beat (MBT mode) or Second (SMPTE-mode)	Scroll Tick (MBT mode) or Frame (SMPTE-mode)
Scrub	Shift	-